

()

Maintenance-free

FR90 fire dampers in short lengths

for installation in rigid walls and ceilings and in metal stud walls

- Sizes: DN 100 mm to DN 315 mm
- lacktriangle Fire classification: El 30/60/90/120 (v_e h_o , i \leftrightarrow o) S
- Options:
 - Protective grille DN 100 to DN 200 for air transfer applications
 - Non-return valves DN 160 and DN 200
 - Limit switch for CLOSED position



Fire damper and optional accessories

Single-piece steel sheet casing made of galvanized sheet steel, longitudinally welded - extremely stable -

- Air-tight and smoke-tight
- Casing leak tightness class C according to EN 1751

Break-resistant damper blade with elastomer lip seal-Leak tightness class 3 according to EN 1751



- · Maximum volume flows
- Minimum pressure loss
- Minimum sound levels




Optional accessories for installation in air transfer applications

• Protective grille SG1 with wide edge for installation flush with the wall. \Rightarrow see pages 3 and 8 to 10



- Protective grille SG2 with narrow edge for installation with excess lengths.
 - \Rightarrow see pages 3 and 8 to 10







Description

Maintenance-free FR90 fire dampers according to EN 15650: FR92K series, short length 150 mm

Fire classification: EI 30/60/90/120 ($v_e - h_o$, i \leftrightarrow o) S

Declaration of performance: DoP no.: CPR/FR90/003

• FR90 fire dampers are essentially made from non-combustible building materials. Certification: Certificate MPA-BS 6000/593/18

Nominal sizes DN [mm] 100 - 125 - 160 - 200 - 250 - 315

 Use in air transfer applications is based on compatibility for approval in accordance with the building code in each individual case. Approvals are no longer issued.

Single-piece casing made of galvanized sheet steel with plug connections and lip seals on both sides.

Release element for 70°C nominal temperature.

Casing leak tightness class C according to EN 1751.

Enclosed, maintenance-free drive mechanism outside the casing wall, sealed drive axles made of stainless steel, with red metal bearings.

For installation in rigid walls and ceilings with a thickness of at least 100 mm and in metal stud walls with a thickness of 95 mm or more. Installation can be carried out with the damper blade axis in the vertical or horizontal position, or anywhere in between. Installation with the connecting piece AR and non-return valve must be in a vertical axis position.


Connection to ventilation ducts made from non-combustible or combustible materials, or with protective grille. Optional accessories:

• Limit switch for damper blade position CLOSED. ⇒ see page 11


Optional accessories:

- Connecting piece AS with traverses for screw fastening the protective grille SG1 or SG2 to the operation side L1 or non-operation side L2. Sizes DN 100 to DN 200. ⇒ see pages 2 and 8 to 10
- Connecting piece AR with non-return valve and traverse for screw fastening the protective grille SG1 or SG2 on the non-operation side L2. Sizes DN 160 to DN 200.

 ⇒ see pages 2, 8 to 10
- Protective grille SG1 with wide edge for installation flush with the wall or in combination with the duct frame RB. Sizes DN 100 to DN 200. ⇒ see pages 2 and 8 to 10
- Protective grille SG2 with narrow edge for installation flush with the connecting piece AS. Sizes DN 100 to DN 200. ⇒ see pages 2, 8 to 10
- **Duct frame RB** for covering connecting piece and protective grille SG1 which protrude from the wall. Sizes DN 100 to DN 200. ⇒ see pages 2 and 8 to 10



- 1 Casing
- 2 Damper blade
- 3 Damper blade seal
- 4 Release element with pipe fusible link 70°C
- 5 Fusible link holder on the casing
- Enclosed closing spring actuator
- 7 Bearing axis
- 8 Plug connection with lip seal
- 9 Limit switch (optional)
- 10 Fusible link holder on damper blade





			Protective			
DN	Ød	U	A_A	A _{free}	Weight	grille A _{free}
	[mm]	[mm]	[m ²]	[m ²]	[kg]	[m ²]
100	99.3	0	0.0068	0.004	0.565	0.0049
125	124.3	0	0.0110	0.008	0.685	0.0081
160	159.3	5	0.0185	0.014	0.865	0.0138
200	199.3	25	0.0293	0.024	1.105	0.0221
250	249.3	50	0.0465	0.038	1.715	-
315	314.3	85	0.0747	0.064	2.415	-



Dimensioning (1) pressure drop, sound power level with ventilation duct connection on both sides

Installation on both sides with ventilation duct connection





FR90 fire dampers, series FR92K, can be used at a velocity of up to 15 m/s in the inflow cross-section $\boldsymbol{A}_{\!\boldsymbol{A}}$ and up to 2500 Pa operating pressure.

Example:

Both sides with ventilation duct connection

V $= 468 \text{ m}^3/\text{h}$ DN 160 mm 6.5 m/s 15 Pa 40 dB(A)

Nomenclature


 L_{WA}


DN	[mm]	Nominal size
A_A	[m²]	Inflow cross-section
A_{free}	[m²]	Free cross-section fire damper or protective grille
V	[m³/h]	Volume flow
$\Delta \rm p_{\rm s}$	[Pa]	Static pressure drop
V_A	[m/s]	Flow velocity in inflow cross-section (= inflow velocity)
ΔL	[dB]	Relative sound power level to L_{WA}
f	[Hz]	Octave mid frequency
L_{WA}	[dB(A)]	A-weighted, area-corrected sound power level



Dimensioning (2) pressure drop, sound power level with protective grilles connection


Installation on one side with ventilation duct connection and protective grille






free incoming flow - exhaust air-

Installation on both sides with protective grille in air transfer applications





Installation on both sides with protective grille and non-return valve in air transfer applications

DN		n the opening direction tial pressure of	Leak tightness class according to EN 1751 with closed non-return	
	25 Pa	50 Pa	valve and 25 to 300 Pa differential pressure in the closing direction	
160	110	250	≥ 2	
200	270	460	≥ 2	



Installation in general


FR90 fire dampers, series FR92K,


must be installed in \geq 100 mm thick rigid walls and ceilings, or in \geq 95 mm thick metal stud walls, each with the appropriate fire resistance period.


The circumferential gap "s" and the installation gaps between fire dampers must be ≥ 15 mm wide. The fillings or mortaring must be made as uniformly as possible on both sides of the damper blade, and should be ≥ 95 mm deep overall.

Fillings are made manually or mechanically with mortar of groups II or III according to DIN 1053 or with mortar of classes M2.5, M5, M10 or M20 according to EN 998-2 or with the respective fire protection mortar or gypsum mortar.

Gaps can be additionally filled as required. The same applies in the area of the connecting pieces. Special fillings are indicated below.








The damper blade axis and the closing spring actuator are shown here in horizontal position.

When using the connecting piece AR and the non-return valve, the damper blade axis and the closing spring actuator must be installed vertically! ⇒ see page 9


Rotation of the fire damper by up to 360° is also permitted so that intermediate positions with appropriate installation positions of the closing spring actuator are possible.


Installation in walls


Operation sides



Installation in ceilings








Suspended in ceilings


Connection types


Installation on both sides with duct connection


Installation on one side with duct connec- Installation in air transfer applications tion and with protective grille on other side

with protective grille on both sides










* fill out as required

Flush with the wall




Installation in rigid walls and ceilings and in metal stud walls




Rigid walls and ceilings can be made of concrete, lightweight concrete, porous concrete (aerated concrete) or plaster. They can be a masonry or wallboard construction and must have a bulk density of ≥ 450 kg/m³. Walls may also be configured as fire walls, shaft walls, shafts or ducts.

Required minimum thicknesses for installation of the fire damper W, D [mm]:



Installation opening a x b or \emptyset d for mortar filling: $a \ge DN + 25 mm$ $b \ge DN + 50 mm$ $d \ge DN + 50 \text{ mm}$

	_
	30
Fire resistance period in minutes	60
	90
	120
Rigid walls	100
Rigid ceilings	100



with mineral wool


The metal stud walls must be clad with at least 2 layers of 12.5 mm DF gypsum boards according to EN 520. GKF gypsum boards, Fermacell boards or other equivalents must be used. The metal stud distances (spans) can be up to 1.000 mm. Profiles for metal stud walls are described in DIN 18182 and EN 14195, constructions in DIN 18183.

> Required minimum thicknesses W for installation of the fire damper [mm]:

The dimensions of the installation opening for mortar filling can be as above for rigid walls.

Fire resistance period in minutes	30 60 90 120 ¹⁾
Metal stud wall	95

¹⁾ for installation with mineral wool up to DN 200 only!



Installation opening

The following is required in the wall claddings:

- U frame a x b \geq DN + approx. 50 mm
- Installation opening Ø = DN + approx. 6 mm
- Notch = 35 x 25 mm and as follows
 - on one side for a wall thickness of > 125 mm
 - on both sides for a wall thickness < 125 mm.

The space around the enclosure of the fire damper must be filled with mineral wool with a bulk density of \geq 100 kg/m³ up to the U frame.


Installation recommendation

- Construct metal stud wall with an installation opening and apply cladding on the one side.
- Fill installation opening with mineral wool and apply a second cladding.
- · Cut installation opening in claddings and mineral wool filling and chamfer them all around.
- · Insert and align fire damper.
- · Seal remaining joints with gypsum filler or equivalent.


All dimensions in mm




Installation in air transfer applications with protective grille on both sides; without non-return valve




The damper blade can be installed with the axis in the vertical or horizontal position, or anywhere in between; the same applies to the protective grille and connecting pieces.





Installation flush with the wall



Installation with excess lengths \ddot{U}_1 and / or \ddot{U}_2

If \ddot{U}_1 = L1, \ddot{U}_2 = L2 + 100 mm - wall thickness W

When the fire damper is open, the flow direction can be from

Connection length on the

- Operation side L1
- Non-operation side L2

Excess length on the

- Operation side Ü₁
- Non-operation side Ü₂


All dimensions in mm

Minimum wall thicknesses for protective grille SG1 installation flush with the wall


	Wi	thout non-return valve =	⇒ see page 8	With non-return valve ⇒ see page 9			
DN	Wall thickness W [mm]	Connecting piece AS Length L1	Connecting piece AS Length L2	Wall thickness W [mm]	Connecting piece AS Length L1	Connecting piece AR Length L2	
100	≥ 210	55	55	≥ 210	55	55	
125	≥ 210	55	55	≥ 210	55	55	
160	≥ 210	55	55	≥ 210	55	55	
200	≥ 220	75 Shorten on-site to 60 mm	75 Shorten on-site to 60 mm	≥ 235	75 Shorten on-site to 60 mm	75	



Installation in air transfer applications with protective grille on both sides and with non-return valve




The fire damper and the connecting piece AR with non-return valve must be installed with vertical axes. All longitudinal pipe cuts are then horizontal. A maximum deviation of $\pm \, 5^{\circ}$ is permissible.




Install connecting piece AR with the non-return valve on non-operation side L2 of the fire damper.


To do so \geq 3 mm excess length from the finished wall surface.



Non-return valve installation



Installation flush with the wall



Installation with excess lengths $\ddot{\rm U}_{\rm 1}$ and/or $\ddot{\rm U}_{\rm 2}$

If \ddot{U}_1 = L1, \ddot{U}_2 = L2 + 100 mm - wall thickness W

When the fire damper is open, a single-sided flow direction is possible.

Locking mechanism of the non-return valve

Connection length on the

- Operation side L1
- Non-operation side L2

Excess length on the

- Operation side Ü₁
- Non-operation side Ü₂

⇒ see table on page 8

All dimensions in mm

Optional accessories

Connecting pieces AS made of galvanized sheet steel are for fitting onto the fire damper plug connections fitted with lip seals. Traverses are for screw fastening the protective grille SG1 or SG2 to the connecting pieces.

Sizes:	DN 100	DN 125	DN 160	DN 200
Lengths L ₁ , L ₂ [mm]	5	75, 100		

The lengths 75 mm and 100 mm of sizes DN 100, DN 125 and DN 160 can be shortened by the customer to 55 mm, those of the sizes DN 200 can be shortened to 60 mm.

Connecting pieces AR made of galvanized sheet steel with an aluminium **non-return valve** are for fitting onto the inflow side fire damper plug connection fitted with lip seals. Traverses are for screw fastening the protective grille SG1 or SG2 to the connecting piece AR.


The non-return valve opens in the specified flow direction automatically and with a pressure delay. It closes if there is a return flow or no flow.


Sizes:	DN 160	DN 200
Lengths L ₂ [mm]	55	75

Protective grille SG1 with wide edge made of powder-coated, galvanized sheet steel in the colour RAL 9010 (pure white).

Sizes:	DN 100	DN 125	DN 160	DN 200
Ø D₁ [mm]	125	145	185	235

Pack: Protective grille SG1, fastening screws M5 x 6 and M5 x 10, mount and screw covers.





Protective grille SG2 with narrow edge made from galvanized sheet steel powder-coated in shade RAL 9010 (pure white).

SG₁


Sizes:	DN 100	DN 125	DN 160	DN 200
Ø D _o [mm]	106	131	166	206

Pack: Protective grille SG2, fastening screws M5 x 6 and M5 x 10, mount and screw covers.

Duct frame RB in the RAL colour 9010 (pure white) for covering protruding connecting pieces.

Duct frames must be used together with the protective grille SG1 and can be shortened by the customer to the excess length $\ddot{\text{U}}$. They are secured between the wall and protective grille SG1 with their screw fastening.

Size	DN 100	DN 125	DN 160	DN 200
Length L [mm]	50 or 100			



Δ




Optional accessories, installation, maintenance-free, functional test and servicing

Limit switches for signalling the damper position CLOSED can be retrofitted and must be installed on site.


Pack: Limit switch, cable tie, end nipple for casing wall installation, strain relief, installation instructions.

Electrical connection:



Assembly:

The connection cable must be routed towards the outside on the operation side (release element side) of the fire damper. It must not obstruct the cover level or the damper blade.



Installation

• FR90 fire dampers, series FR92K, must be installed according to the instructions in this user manual.

Structural requirements for walls, ceilings, ventilation ducts etc. must be met by the customer.

The technical regulations and national statutory regulations must be observed during installation.

In Germany, this means the "Technical Building Regulations" (VV TB) and the "Guideline on Fire Protection Requirements Pertaining to Ventilation Systems" (Lüftungsanlagenrichtlinie - LüAR).

 FR90 fire dampers, series FR92K, may be connected to ventilation ducts made of non-combustible and combustible materials. Thermal expansion in case of fire must not subject the fire dampers to notable forces. Compensatory measures must be provided as required. In general, the compensation is achieved by routing ducts appropriately.

• FR90 fire dampers, series FR92K

- Do not need spacing to separate from combustible materials.
- Are suitable for all installation positions.
- Can be installed with a minimum distance of 15 mm, also in metal stud walls.
- Electric wiring must be performed on site.

Maintenance-free

 FR90 fire dampers, series FR92K, are maintenancefree as a result of the full enclosure, corrosion-resistant materials and precise manufacture.

The stainless steel operation mechanics are situated in an enclosure, not in the air flow. There is no requirement for recurrent cleaning and lubrication.

Damper blades are break-proof. Seals and other materials are engineered to be durable.

Functional testing and servicing

- Fire dampers must be maintained by the owner.
 Functional checks should be performed periodically and depend largely on operation of the system. The regulations must be adhered to.
- Repairs or service work are required in the event of malfunctions. Original spare parts must be used.
- Cleaning work required in ventilation systems for hygiene reasons must be performed in an operationdependent manner, and also includes the fire dampers.


Operating instructions for FR92K series FR90 fire dampers available for download at www.wildeboer.eu




Order data

 pcs fire dam	per FR9	2K					FR92K -	
DN size	100	125	160	200	250	315		
	10	12	16	20	25	31		
 pcs limit sw i	itch ES						FR92K - ES	
 pcs connect	ing piec	e AS	withou	t non-r	eturn v	valve	FR92K - AS	
DN size	100	125	160	200				
_	10	12	16	20				
	5	5	5	-				
75 [m m] 100	7	7	7	7				J
100 ٿ	10	10	10	10				

 pcs co	onnec	ting piec	e AR	with no	on-retu	FR92K	- AR	 _	
DN si	ze	-	-	160	200				
_		-	-	16	20				
ngth mm]	55	-	-	5	-				
e-	75	-	-	-	7	1			





pcs duct fra	me RB ¹)	FR92K - RB		
DN size	100	125	160	200	T
	10	12	16	20	
	5	5	5	5	
-ength	10	10	10	10	

¹⁾ Can only be used with protective grille SG1.

Ordering examples:

50 FR92K fire dampers, DN315

15 duct frames RB DN160, length 50 mm

15 protective grilles SG1 with wide edge DN160

20 connecting piece AR with non-return valves DN200, length 75 mm

50 pcs FR92K-31 15 pcs FR92K-RB-16-5 15 pcs FR92K-S1-16

20 pcs FR92K-AR-20-7

All dimensions in mm



Specification text

Maintenance-free fire damper according to EN 15650 with up to 120 minutes fire resistance period. Fire classification EI 30/60/90/120 (ve - ho, i \leftrightarrow o) S. Air-tight casing in galvanized sheet steel, leak tightness class C according to EN 1751. With plug connections and lip seals on both sides. Enclosed and maintenance-free operation mechanics arranged outside the casing wall. Drive axles made of stainless steel, red metal bearings. For installation in rigid walls and ceilings and in metal stud walls. Release $70\,^{\circ}\text{C}$.

With electrical limit switch for signalling the blade position ${\tt CLOSED.}$

With connecting piece made of galvanized sheet steel on one side / on both sides, and with a traverse for screw fastening a protective grille.

With connecting piece made of galvanized sheet steel on one side, with metal non-return valve, and with a traverse for screw fastening a protective grille.

With protective grille made of galvanized sheet steel on one side / on both sides, powder-coated in the colour RAL 9010. With wide edge and 12 mm mesh size.

With protective grille made of galvanized sheet steel on one side / on both sides, powder-coated in the colour RAL 9010. With narrow edge and 12 mm mesh size.

With duct frames made of galvanized sheet steel on one side / on both sides, powder-coated in the colour RAL 9010.

..... pc

Diameter DN: mm

Volume flow: m³/h

Pressure drop: Pa


Sound power level: dB(A)

Manufacturer: WILDEBOER

Type/series: FR90/FR92K

deliver: install:

INNOVATIVE · PRACTICAL · ECONOMICAL



TAKE ADVANTAGE OF OUR STRENGTHS!



air distribution | fire protection | noise protection | building control systems